



Hello!

Model: LPB-P221
Strong Powerbank
User Manual

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

Dear Customer

Thank you for choosing LinkTech's products, we appreciate your choice to purchase this product and we're hoping that you'll have a great time using our product.

Please share your experience with our products through LinkTech's customer services center either by phone, Whatsapp or Bip.

Feel free to express your opinions or tell us your suggestions on our channels. LinkTech will happily review all your invaluable feedback in order to improve our products and services.

If you encounter any problem or have difficulties with this product, please refer to the User's Manual, you can contact our customer services if you have any further questions.

LinkTech considers your priceless recognition and support as an encouragement to stay focused on providing high quality products and a motivation to move forward, improve our services and expand our workspace in the future.

LinkTech's Sales Team

Strong Powerbank



Product Characteristics and Features

- High Density 10000mAh Lithium-Polymer battery
- A robust outer shell made from fire-proof ABS and PC materials
- Light-weight, compact and modern design
- Support PD Power Delivery Technology for faster charging time.
- Built-in USB Type-C output port, 22.5W max
- Built-in USB-A output port, with Power Delivery Technology support, 22.5W max
- Built-in Lightning cable for charging Apple products, 12W max
- built-in USB Type-C cable, for Turbo and Fast charging devices with Power Delivery Technology support, 22.5W max
- Embedded digital screen to show the battery's remaining charge
- Advanced circuit with multi-layer protection against common mechanic and electric factor.

Specifications

Model Number	LPB-P221
Indicator	Numeric LED Digital Screen
Battery Description	Lithium Polymer 10000mAh
Lightning Cable Output	5V – 2.4A (12W)
Type-C Cable Output	12V – 1.6A/9V – 2A/4.5V – 5A/5V – 3A (22.5W)
USB Output	12V – 1.6A/9V – 2A/4.5V – 5A/5V – 3A (22.5W)
Type-C Output	12V – 1.6A/9V – 2.2A/5V – 3A (20W)
Type-C Input	12V – 1.5A/9V – 2.2A/5V – 3A (20W)
Micro Input	12V – 1.5A/9V – 2A/5V – 2A (18W)

Product Introduction



Usage Instructions

Recharging The Powerbank:

- Charge the powerbank to 100% when you use it for the first time.
- This powerbank has a numeric LED digital screen to indicate the battery's remaining charge, if the number drops below 20%, it's recommended to recharge the powerbank back to at least 80% or higher for optimal performance and to ensure the battery's longevity
- Connect the USB Type-C port to any charging device in order to recharge the powerbank's battery, this port is compatible with many fast charging protocols with maximum input power is 20W.

Charging Phones and Other Devices:

- Use the built-in **Lightning Cable** to charge any iPhones, iPad or Apple Devices, just attach the cable to device, this cable can provide up to 12W and it's Apple MFI certified.
- Use the built-in **USB Type-C Cable** to charge any compatible devices, just attach the cable to device, this cable can provide up to 22.5W with PD technology support
- Use the built-in **USB-A** output port to charge any compatible devices, just connect the device with this port through a compatible cable, this port can provide up to 22.5W with PD technology support.

Usage Instructions

Charging Phones and Other Devices:

- Use the built-in **USB Type-C** port to charge any compatible devices, just connect the device with this port through a compatible cable, this port can provide up to 20W with fast charging support

Note: USB Type-C Port can either be used as an input port for charging the powerbank, or an output for charging another devices.

Attention

1. Please check carefully your device's supported input voltage and current before charging it, any incompatibility or improper use will reduce the battery life or even cause damages to either powerbank or connected device.
2. Please use a USB AC adapter or a Computer's USB port with 5V DC to recharge the powerbank.
3. Please make sure that your device is compatible with this powerbank's output voltage and current before attaching it to the powerbank.
4. When there is something wrong with the powerbank's temperature, colour or shape, stop using it immediately and contact local distributors.
5. Please make sure to fully recharge the powerbank at least once every three months.

Attention

- When using the powerbank it may become warm but not very hot.
- When charging your device with this powerbank, please make sure that your device is in charging state.
- Please make sure the powerbank is ON before attaching it to another device, similarly, after charging your device is finished, make sure the powerbank is OFF to avoid power loss.
- When recharging the powerbank, remove it first, then remove the adapter from AC outlet to save energy.
- Any inappropriate use may cause damages or reduce your powerbank's lifetime, the manufacturer is not responsible in the case of misusing or abusing the product.

FAQs

FAQ	Reasons
Powerbank cannot be recharged	<ol style="list-style-type: none">Using a defected, damaged or broken charging cableThe charging cable is not connected correctly or a little loose.AC adapter is broken, not working or there is no electricity at the AC outlet
Connected devices cannot be charged by this powerbank	<ol style="list-style-type: none">Using a defected, damaged or broken cableThe cable / connector is not attached correctly or a little loose.Low voltage, please recharge the powerbanksA problem with the powerbank, please contact local distributors

Warnings

1. Keep this product away from water and fire, and within -10°C to $+45^{\circ}\text{C}$ temperature range
2. This product contains electrical components, Do Not treat this product as a toy.
3. Do not disassemble, dismantle or change the structure of this product
4. Do not scratch the product's surface with a sharp object, do not shake it or throw it intentionally
5. Use a soft and dry cloth to clean this product, keep it away from chemical cleaning agents



Importo Firma
LINK-TECH TRADING COMPANY LIMITED
FLAT 609A,6/F, FOOK CHONG BUILDING 63 HOL YUEN
ROAD,KWUN TONG,KOWLOON,HONG KONG
TEL:3114 7567



WARRANTY CERTIFICATE

This document has been prepared by taking into account the principles of

WARRANTY CERTIFICATE of Consumer Protection Law No. 6502.

WARRANTY CONDITIONS

- 1) Warranty period is 2 years from the delivery date of the goods.
- 2) All parts of the product are guaranteed.
- 3) If the goods are found to be defective, the consumer, 6502 Article 11 of the Law on Protection

A- Return from contract

B- Requesting discounts

C- Free repair request

D- May take the right to ask for the sale to be replaced with a non-defective product.

- 4) If the consumer chooses the right to free repair from these rights seller; It is obliged to make or repair the goods without any charge under the cost of labor, replacement parts or any other name.

The consumer can also use the right to free repair against the manufacturer or importer. Seller, manufacturer and importer are responsible for the consumer's right to use this right.

- 5) If the consumer uses the right of free repair,

- Failure to repeat within the warranty period

- Exceeding the maximum time required for repair

- In cases where it is not possible to establish a report by authorized service station, dealer, manufacturer or importer; the seller can demand the return of the price of the goods, the price reduction at the price of shame or the replacement of the goods with the non-defective product if possible.

The seller cannot refuse the consumer's demand. If this request is not fulfilled, the seller, the manufacturer and the importer shall be jointly responsible.

6) The repair period of the goods can not exceed 20 working days. This period starts at the date of notification of the defect to the authorized service station or the seller within the warranty period and the date of delivery of the goods to the authorized service station.

If the defect, goods, manufacturer or importer is not repaired within 10 working days; Until the repair of the goods has been completed, it should allocate another product with features similar to consumer use. In case of malfunction of the goods within the warranty period, the time spent in the repair is added to the warranty period.

7) The use of the product contrary to the instructions in the manual is not covered by the warranty.

8) The consumer may apply to the Consumer Arbitration Committee or the Consumer Court at the place of settlement of the disputes that may arise in relation to the use of the rights arising from the warranty or in the place where the consumer transaction is made.

9) In the event that this Warranty Certificate is not provided by the Seller, the consumer may apply to the General Directorate of Consumer Protection and Market Surveillance of the Ministry of Customs and Trade.

