



Model: LPW-S100 Kids Smart Watch **User Manual**



2MP Camera













Note: Waterproof performance

1. What's in the box

Kids	Charging	User	Card
Watch	Cable	Manual	Picker
1	1	1	1










2. Kids Smart Watch Display

Front side:



Warning: Do not poke the mic and air vent with sharp objects such as card removal pins.



3. Choosing Correct SIM Card

Choose operator with 2G, 3G, or 4G network Use Nano SIM card only

Before using the watch, please make sure SIM card is active and capable of using 2G, 3G, or 4G data







Normal SIM

Micro SIM

Nano SIM

4. SIM Card Installation

Please read carefully before turning the smartwatch on, to avoid any problem caused by wrong SIM card installation.





Open and pull out the card slot with SIM card picker.





Put the SIM Card into card slot, CHIP UPSIDE. and insert it in the watch

Note: For new SIM card, Do not install the SIM card until activation is done



3. Choosing Correct SIM Card

Download Trackingo APP through one of followig methods:

- 1. Scan QR code to download APP
- 2. https://lageniotech.com/supportpage
- 3. Download from Apple App Store and Google Play Store



Scan QR Code and Download "Trackino" APP



6. Register & Login with "Trackino"



6. Register & Login with "Trackino"



Setting Login Password



Bind Watch



Scan the Watch OR code



7. Scan QR Code and Bind Watch

- 1. Turn on App and Login on your smart phone.
- 2. Click on Bind Watch icon, tap "Find Bind Number" and scan OR code to bind the watch.





- 1 Slide left on main interface to find the Bind function, click it to enter and obtain a binding
- code 2. Scan OR code or enter the bind code manually.



Enter Your Name



Enter Watch's Name



Rind Process Completed



8. Function Button Operations

Download Trackingo APP through one of followig methods:

- 1. Scan QR code to download APP
- 2. https://lageniotech.com/supportpage
- 3. Download from Apple App Store and Google Play Store



Function Button

- Long press to turn on (If watch can't turn on, please confirm whether the watch is out of power)
- · Short press to turn off/on screen
- One-tap SOS

Long press for 5s to send emergency call (Need to set emergency contact person in APP)

Remind: If the new watch cannot be turned on, it is likely that the watch is out of power.

Please plug in the charging cable until the watch shows the charging interface.

9. Basic Operations



Main interface

Slide right on main interface to enter weather Slide left on main interface to enter Phone, SMS, Chat, Add Friend, Camera , Gallery, Steps, Bind, StopWatch, Calculator, and more



10. Charging

Please plug the charging caple correctly into the charging contacts on the watch's backside, the charging interface will appear on the screen.





11. Basic Functions



Phone

Click "Phone", Select a contact to make a phone call; if you can't make a call, please check whether the contact is added on APP.



SMS

Click "SMS", You can view the text message content, you can click "SMS" icon editing content Reply.



Chat

On "Chat" page, press and hold "HOLD" to record voice, and then release to send voice. Click on unreaded messages on the screen to play recieved voice message.



Add Friends

After inserting a SIM Card, On "Add Friends" page, Click on the search friend when you add a friend interface. Users will choose to add.



Camera

Click "Camera" to start to take pictures. You can view and delete photos in "Gallery".



Gallery

You can view and delete photos in "Gallery".



Steps

To view the number of your daily steps.



StopWatch

The stopwatch starts counting after the point starts, which is convenient for you to calculate time, and can be reset with onen key after stopping the stopwatch.



Calculator

To do numerical calculations.



More

More features such as: Contacts, Alarm, Gallery, Stopwatch, SMS, and Settings

Video call

Method 1: Click "Phone", click to enter "Contact"-page 1, select contact, you can make video call-page 2;

Method 2: Click "Chat" to enter the "Contact List interface-page 3, select contact People, enter the chat interface-page 4, left sliding chat interface, video call-page 5;

Video call will use data, you may connect Wi-Fi for video call.



Remind: Long video calls will cause the watch to heat up. Please do not make video calls for a long time. Please do not wear the watch when the high temperature alarm pops up.

Wear the watch after the temperature drops to avoid high temperature scald

Wi-Fi Setting

After binding the watch, open "More"->Setting-> WLAN -> Set up Wi-Fi.

Positioning

Turn on App, click "Location" to check GPS track and positioning.

12. Specifications

Waterproof	IP68	
CPU	SL8541E	
Battery	720mAh	
OS	Android 8.1	
Camera	2MP	
SOS	Support	
Display	1.78 inch HD screen	
Resolution	240 x 280	
Sensor	Accelerometer	
Dimensions	58.3x42.0x15.55mm	
Memory	RAM 1GB+ROM 8GB	
Positioning	GPS/LBS/A-GPS/WiF/Accelerometeri	
Compability	Android 4.4+ and iOS 9.0+	
Display	1.78" inch HD AMOLED screen	
FDD/TDD Band	1/3/7/8/20+W:900/2100 + GSM:900/1800	

